



ULTRA HIGH POWER FIXED ATTENUATOR RFS10KG1

- Ultra high power 10KW CW
- Ultra high peak power 200KW (5us)
- Wide band operation
- Low VSWR and flat response
- Oil cooling plus Air cooling.
- Applications: Broadcasting, defence, radar communication



10K WATTS ULTRA HIGH POWER FIXED ATTENUATOR

Electrical Specifications			
Frequency Range:	DC-1.0GHz	VSWR max.	1.40 : 1
Attenuation:	20dB, 30dB, 40dB, 50dB	Flatness	± 1.0dB (DC-0.5GHz) ± 1.5dB (0.5-1.0GHz)
Power handle	10 KW (CW)	Peak Power	200KW (5us pulse)
Mechanical and Environmental Specifications			
Operation Temperature:	-10°C to 50°C	Storage Temperature:	-40°C to 70°C
Connector:	L27, L29, L36, L52, EIA 5/8"	Dimension:	870 x 330 x 910mm (34.25" x12.99" x35.83")
Weight:	110Kg		
Operation Instruction:	<ol style="list-style-type: none"> 1. Connect input and output of attenuator to 50Ω impedance system. 2. Turn on air cooling FAN and verify the FAN is working properly. 3. Turn on system power. If possible, start from lower power, and increase the power step by step. 4. Before disconnect the attenuator, make sure turn off all the power (RF power and DC power) first. 5. Keep the air cooling FAN running until the attenuator case temperature reach room temperature. 		
WARNING:	<ol style="list-style-type: none"> 1. Input average power must be < 10KW CW 2. This is directional attenuator. DO NOT CONNECT output port to input. 3. The unit is designed for Indoor application only, prevent all shock, vibration and humidity. 		
MAINTAINANCE	<ol style="list-style-type: none"> 1. Check input and output impedance before each time operation. The impedance should within 50Ω ± 2Ω. 2. Check cooling oil regularly in every 500 hours. Cooling oil color should be light yellow. If oil color turn to black or dark brown, it may be contaminated. Then the oil need to be replaced. 3. Clean input and output connector by alcohol regularly. 		